
TOP OF TOWER PARAPET LVL.+160250
WATER TANK LVL.+157090
MACHINE ROOM LVL.+152840
TERRACE FLOOR LVL.+149640
PENTHOUSE FLOOR FFL
PENTHOUSE FLOOR TOS LVL.+145190
40TH FLOOR LVL.+141840
39TH FLOOR LVL.+138440
38TH FLOOR LVL.+135040
37TH FLOOR LVL.+131640
36TH FLOOR LVL.+128240
35TH FLOOR (REFUGE) LVL.+122950 HEIGHT FROM FTP=122050
34TH FLOOR LVL.+121440
33TH FLOOR LVL.+118040
32ND FLOOR LVL.+114640
31ST FLOOR LVL.+111240
30TH FLOOR LVL.+107840
29TH FLOOR LVL.+104440
28TH FLOOR LVL.+101040
27TH FLOOR LVL.+97640
26TH FLOOR (REFUGE) LVL.+92350 HEIGHT FROM FTP=91450
25TH FLOOR LVL.+90840
24TH FLOOR LVL.+87440
23TH FLOOR LVL.+84040
22TH FLOOR LVL.+80640
21ST FLOOR LVL.+77240
20TH FLOOR LVL.+73840
19TH FLOOR LVL.+70440
18TH FLOOR LVL.+67040
17TH FLOOR (REFUGE) LVL.+61750 HEIGHT FROM FTP=60850
16TH FLOOR LVL.+60240
15 FLOOR LVL.+56840
14TH FLOOR LVL.+53440
13TH FLOOR LVL.+50040
12TH FLOOR LVL.+46640
11TH FLOOR LVL.+43240
10TH FLOOR LVL.+39840
9TH FLOOR LVL.+36440
8TH FLOOR LVL.+33040
7TH FLOOR LVL.+29640
6TH FLOOR LVL.+26240
5TH FLOOR LVL.+22840
4TH FLOOR LVL.+19440
3RD FLOOR LVL.+16040
2ND FLOOR LVL.+12640
1ST FLOOR LVL.+9240
LOBBY LEVEL LVL.+3240
DROP-OFF LVL.+3090
INTERNAL ROAD (FIRE TENDER PATH) LVL.+2790
EXTERNAL ROAD LVL ±00
BASEMENT 1 LVL.-2710
BASEMENT 2 LVL.-6310
BASEMENT 3 LVL.-9910
3200
4250
3700
3950
3350
3450
3400
3400
3400